



PARTS LIST

| | | | |
|-----------------------|-------------------|---------------------|-------------------|
| 1. HANDLER NUT | 23. RING | 45. FLAT TOWER BOLT | 67. DRIVE PIN |
| 2. W/RETAINER | 24. BALL BEARING | 46. W-PINION CRAB | 68. SPOOL SSSY |
| 3. HANDLE NUT COVER | 25. TAPPING SCREW | 47. BUSH | 69. RING |
| 4. HANDLE SHAFT | 26. PIGHT COVER | 48. WORM SHAFT | 70. BALL BEARING |
| 5. BALL BEARING | 27. PLINION GEAR | 49. SCREW | 71. WASHER |
| 6. HANDLE KNOB | 28. SPRING | 50. PIPE | 72. MAGNET |
| 7. HANDLE SHANK | 29. CLUTCH | 51. PILLAR | 73. SCREW |
| 8. SCREW | 30. TAPPING SCREW | 52. LEVEL WOND | 74. MAGNET HOLDER |
| 9. LEAPT SPRING | 31. CLUTCH CAM | 53. BUSI | 75. SCREW |
| 10. STAR MODE SPANNER | 32. SPRING | 54. WASHER | 76. SPOOL COVER |
| 11. BUSH | 33. KICK LEVER | 55. D-RING | 77. SPRING |
| 12. SPRING PLATE | 34. SPRING | 56. LINE GUIDE | 78. STOPPER |
| 13. SPRING | 35. D-WASHER | 57. LEVEL WIND PIN | 79. STOPPER PLATE |
| 14. WASHER | 36. WASHER | 58. WASHER | 80. SCREW |
| 15. WASHER | 37. DRIVE GEAR | 59. LEVEL WIND NUT | 81. SLIDER A |
| 16. SPRING WASHER | 38. WASHER | 60. SCREW | 82. SPRING |
| 17. WASHER | 39. RACHER | 61. COVER | 83. SLIDER B |
| 18. BALL BEARING | 40. OS GEAR | 62. PIN | 84. SPRING |
| 19. O/WAY CLUTCH | 41. BEARING PLATE | 63. THUMB BAR | 85. CONTROL DIAL |
| 20. PUSH BUTTON | 42. GEAR METAL | 64. SCREW | 86. SCREW |
| 21. RUBBER | 43. D-RING | 65. BALL BEARING | 87. STOPPER LEVER |
| 22. 1/2" O" RING | 44. BALL BEARING | 66. SPOOL SHAFT | 88. LEFT COVER |