



PARTS LIST

1. HANDLER NUT	23. RING	45. FLAT TOWER BOLT	67. DRIVE PIN
2. W/RETAINER	24. BALL BEARING	46. W-PINION CRAB	68. SPOOL SSSY
3. HANDLE NUT COVER	25. TAPPING SCREW	47. BUSH	69. RING
4. HANDLE SHAFT	26. PIGHT COVER	48. WORM SHAFT	70. BALL BEARING
5. BALL BEARING	27. PLINION GEAR	49. SCREW	71. WASHER
6. HANDLE KNOB	28. SPRING	50. PIPE	72. MAGNET
7. HANDLE SHANK	29. CLUTCH	51. PILLAR	73. SCREW
8. SCREW	30. TAPPING SCREW	52. LEVEL WOND	74. MAGNET HOLDER
9. LEAPT SPRING	31. CLUTCH CAM	53. BUSI	75. SCREW
10. STAR MODE SPANNER	32. SPRING	54. WASHER	76. SPOOL COVER
11. BUSH	33. KICK LEVER	55. D-RING	77. SPRING
12. SPRING PLATE	34. SPRING	56. LINE GUIDE	78. STOPPER
13. SPRING	35. D-WASHER	57. LEVEL WIND PIN	79. STOPPER PLATE
14. WASHER	36. WASHER	58. WASHER	80. SCREW
15. WASHER	37. DRIVE GEAR	59. LEVEL WIND NUT	81. SLIDER A
16. SPRING WASHER	38. WASHER	60. SCREW	82. SPRING
17. WASHER	39. RACHER	61. COVER	83. SLIDER B
18. BALL BEARING	40. OS GEAR	62. PIN	84. SPRING
19. O/WAY CLUTCH	41. BEARING PLATE	63. THUMB BAR	85. CONTROL DIAL
20. PUSH BUTTON	42. GEAR METAL	64. SCREW	86. SCREW
21. RUBBER	43. D-RING	65. BALL BEARING	87. STOPPER LEVER
22. 1/2" O" RING	44. BALL BEARING	66. SPOOL SHAFT	88. LEFT COVER