



1	FRAME	16	BALL BEARING	31	RIGHT	46	CLUTCH BAR	61	SPOOL	76	LIFTING
2	FRONT COVER	17	SCREW	32	BALL BEARING	47	CLUTCH CAM	62	SPOOL SHAFT	77	LIFTING SCREW
3	FRONT COVER SCREW	18	HANDLE KNOB	33	ONE WAY CLUTCH	48	RETURN PAWL	63	SPOOL SHAFT PIN	78	O-RING
4	LINE GUIDE ASS`Y	19	HANDLE KNOB CAP	34	ONE WAY SLEEVE	49	R/PAWL SPRING	64	BALL BEARING	79	MAGNETIC KNOB
5	LINE GUIDE PIPE	20	HANDLE NUT	35	DRAG WASHER	50	CLUTCH CAM SPRING	65	SCREW	80	BRAKE SPRING
6	WORM SHAFT	21	HANDLE NUT PLATE	36	WASHER	51	CLUTCH CAM SCREW	66	MAGNET	81	BRAKE SOUND PIN
7	WORM PINION	22	SCREW	37	DRIVE GEAR	52	PINION YOKE	67	MAGNET FRAME	82	C/LOCK BUTTON HOLDER
8	E-RING	23	HANDLE WASHER	38	RATCHET WASHER	53	PINION YOKE SPRING	68	MAGNET FRAME SPRING	83	COVER LOCK BUTTON
9	WORM SHAFT BUSHING	24	STAR DRAG	39	RATCHET	54	PINION	69	MAGNET PLATE	84	CLOCK BUTTON SPRING
10	E-RING	25	STAR DRAG INSERT	40	DRIVE GEAR SHAFT	55	O-RING	70	B/RETAINER SPRING	85	C/BUTTON SOUND PIN
11	LINE GUIDE PAWL	26	WASHER	41	Transmission gear	56	BALL BEARING	71	BALL BEARING	86	SPRING
12	PAWL CAP	27	SPRING WASHER	42	MAIN SHAFT PLATE	57	B/RETAINER SPRING	72	WASHER	87	E-RING
13	HANDLE	28	STAR DRAG SPRING	43	E-RING	58	SPOOL WASHER	73	SCREW	88	LEFT COVER
14	HANDLE SHAFT	29	STAR DRAG PLATE	44	BALL BEARING	59	TENSTON WASHER	74	SPOOL COVER	89	SCREW
15	HANDLE KNOB INSERT	30	RIGHT COVER CAP	45	SCREW	60	CAST CONTROL CAP	75	COVER LOCK PLATE	90	SCREW

