



- 101. Control Knob
- 102.Cast Control Brass Washer
- 103.O-Ring
- 104.Retaining Clip
- 105.Washer
- 106.Copper Bush
- 107.Ball Bearing
- 108.Screw
- 109. Left Side Plate
- 110.Location Pillar
- 111.Pawl Washer
- 112."E"-Retainer
- 113.Bait Clicker Button
- 114.Bait Clicker Button Washer
- 115 .Screw
- 116.Magnetic .Cast Control Knob
- 117.Nut
- 118.Pawl
- 119.Pawl Spring
- 120.Pawl Tension Spring
- 121.Reducing bushing
- 122.Magnetic Spring
- 123.Washer
- 124.Magnetic screw
- 125.Magnetic
- 201.Main Body Assembly
- 202.Click gear
- 203.Ball Bearing
- 204.Spool
- 205.Centrifugal Brake Shoe
- 206.Centrifugal Brake
- 207.Axis
- 208.Ball Bearing
- 209.Worm Shaft
- 210.Line Guard
- 211.Line Guide

- 212.Line Guide Pawl
- 213.Washer
- 214.Line Guide Pawl Cup
- 215.Bushing
- 216. Washer
- 217."E"-Retainer
- 301.Crank Shaft
- 302.Clutch Disc
- 303.Drag Friction Disc
- 304.Main Gear
- 305.Drag Friction Disc
- 306."D" Washer
- 307.Ear Washer
- 308.Cup Washer
- 309.Anti-Reverse Bearing
- 310.Drag Spring Washer
- 311. Washer
- 312. Gear Plate
- 313.Thumb Button
- 314.Latch Spring
- 315.Roke
- 316.Roke Spring
- 317.Pinion Gear
- 318.Worm Gear
- 401.Right Side Plate
- 402.Screw
- 403.Ball Bearing
- 404.Retaining Clip
- 405.O-Ring
- 406.Cast Control Brass Washer
- 407.Cast Control Knob
- 501.Star Drag Handle
- 502.Handle Spring Washer
- 503.Handle
- 504."E"-Retainer
- 505.Handle Nut
- 506.Latch Keeper
- 507.Screw