



1	Screw A	22	Anti-Reverse Ball Bearing sleeve	43	Clutch Pawl Spring A	63	E-ring
2	Latch Keeper	23	Anti-Reverse Ball Bearing	44	Clutch Pawl Spring B	64	Ball Bearing
3	Handle Nut	24	Drag Friction Disc A	45	Main Body Assembly	65	Crankshaft Fixed Washer
4	Handle	25	Carbon Drag Friction Disc A	46	Spool Assembly	66	Level Wind Gear A
5	Handle Spring Washer	26	Anti-Rotate Plate	47	Drag Assembly	67	Right Bushing
6	Star Drag	27	Drag Friction Disc B	48	Ball Bearing	68	Ball Bearing
7	Clicker	28	Carbon Drag Friction Disc B	49	Clicker Gear	69	Worm Shaft Pin
8	Washer	29	Main Gear	50	E-ring	70	Worm Shaft
9	Drag Spring Washer	30	Insulating Sheet	51	Screw H	71	Screw I
10	Decoration	31	Clutch Disc	52	Left Support	72	Protecting cover
11	Screw B	32	Level Wind Gear B	53	Washer	73	Line Guard
12	Cast Control Knob	33	Crankshaft	54	Left Cover	74	Line Guide
13	Clicker Washer A	34	Screw D	55	E-ring	75	Line Guide Pawl
14	Clicker Spring	35	Pinion Gear	56	Washer	76	Line Guide Pawl Cap
15	Clicker Washer B	36	Yoke Spring	57	Clicker Pawl	77	Left Bushing
16	Retaining Clip	37	Yoke	58	Clicker Pawl Washer	78	Ball Bearing
17	Ball Bearing	38	Screw E	59	Clicker Button	79	Knob Support
18	Right Cover	39	Screw F	60	Line Guide Shaft	80	Knob
19	Screw C	40	Clutch Button Link	61	Clutch Pawl	81	Screw
20	Left Cover Fixed Rod	41	Clutch Button	62	Clutch Driver	82	Knob Cap
21	Spring	42	Screw G				