



KEY NO.	PARTS NAMES	KEY NO.	PARTS NAMES
1	HANDLE NUT	44	E CLIP
2	HANDLE NUT WASHER	45	MAIN BODY ASSEMBLY
3	HANDLE NUT SCREW	46	SHAFT
4	HANDLE ASSEMBLY	47	E CLIP
5	WASHER	48	BEARING
6	STAR DRAG	49	E CLIP
7	CLICK TONGUE	50	SPOOL
8	CLICK PLATE	51	SPOOL RATCHET
9	CLICK PLATE HOUSING	52	SPOOL GEAR
10	WASHER	53	E CLIP
11	WASHER	54	SCREW
12	WASHER	55	SCREW
13	BEARING	56	IDLER GEAR
14	SCREW	57	E CLIP
15	SPOOL TENSION KNOB	58	CLICK TONGUE
16	WASHER	59	BEARING
17	WASHER	60	WASHER
18	O RING	61	CLICK PAWL SPRING
19	CLUTCH LEVER SCREW	62	CLICK PAWL SCREW
20	CLUTCH LEVER	63	LEFT SIDE PLATE
21	CLUTCH CAM	64	WASHER
22	SPOOL TENSION KNOB	65	CLICK BUTTON
23	CLUTCH PLATE	66	SCREW
24	SCREW	67	SLEEVE
25	RIGHT SIDE PLATE	68	CLUTCH SHELL
26	YOKE SPRING	69	KEY WASHER
27	PINION GEAR	70	DRAG WASHER
28	YOKE	71	EAR WASHER
29	ANTI-REVERSE PALTE PIN	72	DRAG WASHER
30	ANTI-REVERSE PALTE	73	KEY WASHER
31	ANTI-REVERSE SPRING	74	DRAG WASHER
32	SCREW	75	MAIN GEAR
33	BEARING HOUSING	76	DRAG WASHER
34	E CLIP	77	RATCHET
35	BUSHING	78	DRIVE SHAFT
36	PILOT GUIDE CAP	79	BUSHING
37	WASHER	80	SUPPORT PLATE
38	PILOT GUIDE	81	E CLIP
39	LINE CARRIAGE ASSEMBLY	82	SCREW
40	WORM SHAFT		
41	LEVEL WIND GUARD		
42	BUSHING		
43	WORM GEAR		