



brake loop	87	control cap	75	spool shaft	63	washer	51	ratchet	39	cluth spring	14
brake bean	88	left cover	76	spool shaft pin	64	E-ring	52	gear shaft	40	pinion gear	15
brake bean holder	89	screw	77	ball bearing	65	pawl cap	53	connecting gear	41	cluth	16
shart-short	90	brake control lever	78	spool assembly	66	return pawl	54	stoper	42	cluth seat	17
		sound pin	79	screw	67	line guide holder	55	ball bearing	43	cluth seat screw	18
		spring	80	front cover	68	holder guide	56	E-ring	44	cluth cam	19
		screw	81	screw	69	key push lever plate	57	screw	45	kick lever	20
		spool cover assembly	82	stoper spring	70	screw	58	carriage screw pin	46	kick lever spring	21
		brake control gear	83	ball bearing	71	key push lever	59	carriage screw gear	47	ball bearing	22
		brake washer	84	O-ring	72	spring	60	ball bearing	48	cluth lever plate	23
		ball bearing	85	brake washer	73	sound pin	61	carriage screw	49	frame	24
		stoper spring	86	cushion rubber	74	chuth lever pin	62	stabilizer bar	50	screw	25

chuth lever	26	handle knob cap	1
click spring	27	handle knob	2
click holder	28	handle knob screw	3
washer	29	ball bearing	4
drag spring washer	30	handle knob insert	5
ball bearing	31	handle nut lever screw	6
one way assembly	32	handle nut lever	7
drag washer A	33	handle screw	8
drag washer B	34	crank assembly	9
drag washer C	35	friction washer	10
drag washer D	36	star handle assembly	11
drag gear	37	right cover cover	12
washer	38	right cover	13
ratchet	39	cluth spring	14
gear shaft	40	pinion gear	15
connecting gear	41	cluth	16
stoper	42	cluth seat	17
ball bearing	43	cluth seat screw	18
E-ring	44	cluth cam	19
screw	45	kick lever	20
carriage screw pin	46	kick lever spring	21
carriage screw gear	47	ball bearing	22
ball bearing	48	cluth lever plate	23
carriage screw	49	frame	24
stabilizer bar	50	screw	25